



Follow the refill replacement procedure.



[www.better-air.com](http://www.better-air.com)



## BioLogic mini

The Only technology  
for total protection of entire indoors space

SURFACES | OBJECTS | AIR



Protects the indoors  
from contaminants  
and allergens



Reduces use of  
chemicals and  
detergents



Restores Ecological  
Balance to our  
environments



Reduces bad odor

# BioLogic mini—first use and refill guide.

The Only technology for total protection of the entire indoor space

1



Place device and refill on a surface

2



Hold the base and the cap

3



Turn the cap counterclockwise

4



unscrew the empty bottle. Carefully unscrew the refill bottle-cap

5



Flip the device on the new bottle

6



Turn the device over the bottle

7



Keep unit and bottle vertical while screw the bottle into base counterclockwise

8



Flip device as shown, reattach cap

9



Close the cap clockwise

10



Device is ready. Follow instructions on your right

## Operations

The device is a dual-purpose dispersion system:

A rapid, light touch of the power button enables the selection of operation modes.

The Green LED should flash once before entering mode one and twice for mode 2

### Mode 1: Continuous dispersion

The device operates as an electronic fogger where a fast cleaning of contaminated areas is desired. Fog the area for about 30 seconds by pointing the device vertically to the floor in all directions of your room/vehicle/office.

### Mode 2: Automated mode

24 X 7 continuous, automatic protection of your space.

The device should momentarily disperse only once an hour for a few seconds

Using Mode 2 alone - the refill should last about 11-12 weeks.

### Shutting down the device


Continued long press the power button for about 3 seconds.

The LED color should turn blank.

### LED color Indications:

 **Green** - device disperses

 **Blue** - Idle between dispersion

 **Red** - Recharge device - connect to the device the supplied C-type cable to a certified USB charger (not supplied)

 **Blue & Red** - The device is properly recharging.

**When LED is Green, but the device does not disperse, the refill's tank is empty. REPLACE REFILL**

